
Mingo Custom Woods

1965 W 4th Street
Colby, KS 67701
(785)462-2200

Jewelry-Closet™ Cabinet Installation Instructions

Read all the instructions before mounting your Jewelry-Closet™ cabinet.

Tools required: #2 Phillips screwdriver.
 Sheetrock saw (or something that will cut a hole in the wall).
 (optional) drill & 3/16" drill bit for drilling hole.

Items provided: (2) 1 1/2" screws

1. Position your Jewelry-Closet™ cabinet on the wall between two 16"OC studs. The height of the cabinet for most people works best with the top of the cabinet about 4 1/2" above the top of the head. You can usually tap lightly on the wall with your knuckles as if you were knocking on someone's door and listen to see where the wall sounds more solid to find the studs. (Be sure there are no water or drain lines behind sheetrock). Most water and drain lines will come from a faucet, sink, bathtub, or toilet that are either on the other side of the wall or directly above or below the wall you are working on. Draw a pencil line around the cabinet to where the cut out will be. Set cabinet aside.
2. Carefully cut the sheetrock out with a saw following the lines you marked earlier. (Be careful no to cut any electrical wires that may be running inside the wall. They should be able to fit behind the cabinet when it is installed.) It is probably easiest to cut across the top and bottom first and then cut the sides following the studs.
3. If you want to predrill holes for screws in the inside of the cabinet you may want to do this before you put the cabinet into the walls. Screws are to be centered vertically in the cabinet and at least 1 1/2" back from the face of the box.
4. Insert the cabinet into the cut out and secure it using the screws provided. (Be sure to keep the trim tight to the sheetrock). Do not over tighten. The screws only need to be snug enough to keep cabinet from moving.